SAMSUNG ELECTRONICS CANADA, INC.

HEADQUARTERS
7037 Financial Drive, Mississauga, Ontario, Canada L5N 6R3
TEL: 1-905-542-3535
www.samsung.ca

SERVICE DIVISION
7037 Financial Drive, Mississauga, Ontario, Canada L5N 6R3
1-800-SAMSUNG (1-800-726-7864)

SAMSUNG ELECTRONICS

AH68-01292E (Rev 0.0)

SAMSUNG

YP-55

DIGITAL AUDIO PLAYER

yepp™

MP3 & WMA Playback
Removable Storage Device
Encoding Function
3D Sound
Upgradable
FM Reception

SRS WOW Surround
MP3 WMA Play back
MP3 Encoding
FM FM Radio

Contents

Preparations

Safety Instructions 4
Features 6
Components 9
Location of Controls (yepp) 10

Connection to Computer

Connecting yepp to PC 12
Manual Installation of USB Driver 16
Using the removable storage....20
- Downloading/Uploading files 20
- Disconnecting the USB cable 21
- Formatting 22

Installing CD Ripper 23

Basic Usage

Listening to Music with yepp 24
Setting up Volume/Hold Functions 25
Changing Modes 26
Recording Voice....27
MP3 Encoding 28
Searching for Music/Voice Files 30
Listening to FM Radio 32
FM Encoding 34

Additional Usage

Loop Repeating 35
Setting up SRS 36
Setting up MENU....37
Repeating Tracks 38
Setting up EQ 39
Managing Files 40
- Deleting 40
- Formatting 41

Setting up DIRECT PLAY 42
Customizing Options (Display) 43
- DISPLAY 44
- BACKLIGHT....44
- BEEP 45
- CONTRAST 45
- SCROLL SPEED 46
- POWER OFF TIME 46
- DEFAULT VOLUME....47
- WOW LEVEL 47
- ENCODE 48

Firmware Upgrade....50

Appendix

Description of Buttons (yepp player) 52
MENU Table 54

Customer Support

Troubleshooting 56
Specifications....58
Safety Information 60
Warranty 62

Safety Instructions

Read and understand all the instructions to avoid injury to yourself and damage to the equipment.

Do not expose to extreme temperatures (above 95°F or below 23°F). Do not expose to moisture.	Do not apply excessive pressure to the device.	Do not let any foreign matter spill into the device.
Do not place heavy objects on top of the device.	Do not expose to chemicals such as benzene and thinners.	Remove batteries when the device is left unused for a long period of time. 
Do not expose to direct sunlight or heat sources. 	Do not store in dusty areas.	Do not try to disassemble and repair the device yourself.

Earphones

Follow Traffic Safety Instructions

- Do not use the earphones while driving an automobile or riding a bicycle.
  It's not only dangerous, but also against the law.
- It may cause an accident if you turn up the volume of the earphones while walking down the street, especially crossing at intersections.

Protect your ears

- Do not turn up the volume too high.
  Doctors warn against prolonged exposure to high volume.
- Stop using the device or turn the volume down if you have ringing in your ears.

Ambient operating conditions

- Ambient temperature: 5°C ~ 35°C (41°F ~ 95°F)
  Humidity : 10 ~ 75%

Environmental Information

- Follow local guidelines for waste disposal when discarding packages, batteries, and old electronic appliances.
- Yepp packages use cardboard, polyethylene etc., and do not use any unnecessary materials.

DIGITAL SOUND yepp

Removable Storage Device

You can easily copy and paste files to the yepp player using Windows Explorer.

Featuring an Encoding Function

You can make a MP3 file out of an source using the ENC jack on the main unit.
You can also convert an FM radio program into an MP3 file in real time.

Upgradable

You can upgrade the built-in programs when available.
Add functions, CODEC, etc.
Please check the yepp home page (http://www.samsungyepp.com) for upgrades.

DIGITAL SOUND yepp

MP3 & WMA Playback

MP3 is an MPEG1 Layer3 audio format.
WMA is a Microsoft Windows Media audio format.

FM Reception

Listening to an FM program is made easy with Auto Search and Frequency Memory functions.

Featuring 3D Sound

The 3D feature adds spaciousness to the sound.

DIGITAL SOUND yepp

Voice Recording Function

You can do a Voice Recording with high quality and use it for a conference.

Sound

You can adjust equalizer manually.

Playing Time

This unit uses one AAA/LR03 alkaline battery. Operation can last up to 15 hours.
Actual playing time may vary according to the type and capacity of the battery.

Components

Player

Earphones
AH30-00056B

USB Cable
AH39-00498A



User manual
AH68-01292E

Installation CD
AH80-00049B

One Battery
(1.5V AAA/LR03 type)
4301-000115

Neck Strap
AH61-01370A

Carrying case
AH61-01369A

Direct Connect
USB Adaptor
AH39-00489A

Line Cable
AH39-00488A

Model	YP-55 H	YP-55 i	YP-55 V
Built-in memory	128MB	192MB	256MB

- The capacity of the useable built-in memory is less than indicated as the internal firmware uses a part of the memory as well.
- Design of accessories is subject to change for improvement without notice.

Location of Controls (yepp)





Display

Inserting a Battery



1 Slide the cover in the direction of the arrow to open.

2 Insert a battery to the right poles + , – and push-close the cover in the direction the arrow as indicated.

How to Use the Carrying Case

Use as follows.



Note :

- Do not place heavy objects on the cover.

Connecting yepp to PC

System Requirements.

- Pentium 133MHz or greater
- Windows 98 SE/ME/2000/XP
- 20MB of available hard disk space
- CD-ROM drive (double speed or greater)
- USB port (1.1) supported
- VGA graphic

Note :

- Install the operating system in Administrator Account mode for Windows 2000 or XP. Otherwise, installation will not be completed.
- Windows ME, 2000 and XP can recognize the driver without installing the provided program. However, you must install the program in order to format yepp and upgrade firmware.
- If the YP-55 program has not been installed in Windows 98, then it will not communicate with your removable disk. You must install the USB driver file first.

Before connecting yepp to PC, make sure to install USB driver. If "**Add New Hardware Wizard**" appears, press the **[Cancel]** button and install USB driver.

Installing software

1 Insert the Installation CD into CD-ROM drive.
The picture shown below appears.
Select **[USB Driver Install]**.

2 Click **[Next]** in the series of windows that appear.



When installation is completed, connect yepp to PC and use it as shown on the next page.

Continued...

Connecting yepp to PC with USB cable

3 Plug one end of the USB cable into the USB port on the back of the PC.

4 Connect the opposite end of the USB cable to the USB cable port on the bottom of the yepp.

- If you disconnect the USB cable from your PC while implementing a command or initializing during USB driver installation, your PC may not function correctly.
- The yepp will automatically turn on.

5 USB driver is installed with a message saying that it is searching for a new device. You may not see the display screen during installation.
Go to the device manager to check that installation has been successfully completed.

6 Upon installation of the USB driver "**SAMSUNG YP-55**" will appear in the **[System Properties] → [Device Manager]**.



Note :

How to check USB driver

Windows 98:
Control Panel → System → Device Manager → Universal Serial Bus controllers/Samsung YP-55 Class
Windows 2000:
Control Panel → System → Hardware → Device Manager → Universal Serial Bus controllers → USB Mass Storage Device
Windows XP:
Control Panel → System → Hardware → Device Manager → Universal Serial Bus controllers → USB Mass Storage Device

7 When USB driver is not Installed automatically, refer to next page.

Note :

For WinXP, the following window will appear whenever you connect the USB cable to your yepp.

Manual Installation of USB Driver

Go to “Downloading/Uploading files” on page 20 if the USB driver is in place.
Follow these steps if the USB driver is not in place :

1 Check the device manager.
Windows 98,ME:
Control Panel → System → Device Manager
Windows 2000:
Control Panel → System → Hardware → Device Manager
Windows XP:
Control Panel → System → Hardware → Device Manager

2 Check if there is a device listed with an exclamation point or a question mark (displayed as unknown device or USB device).

3 Double click on the device listed with an exclamation point or a question mark.

Note :

- If you are using Windows 2000 and your version of Windows does not recognize the USB driver please download and install the latest service pack from windowsupdate.microsoft.com
- The installation method may vary depending on the type of PC or operating system. Contact your PC dealer or service center for installation information.
- If errors occur continuously when you install the USB driver, reconnect the USB cable after rebooting your system.

4 After selecting the driver, click on **[Update Driver]**.



5 Select a compatible driver, click on **[Next]** to finish.

For Windows 98, refer to page 18.

Continued...

In Windows 98

Click **[Next]** button in the series of windows that appear.

USB driver location
[CD ROM]\setup\Drivers



● You must reboot your computer to complete the installation.

Using the removable storage

Downloading/Uploading files

1 Turn on the yepp and connect yepp to PC.

2 Open Windows Explorer on PC.

3 Select the file to save and drag-and-drop it into the removable disk icon.



Notice :

- The “WRITING/READING” message will appear during file download or upload. Disconnecting the USB cable while “WRITING/READING” is displayed may cause malfunction of the unit.
- Files within a user created folder can only be played in Music Mode.
- The order of music files is not relative to the replay order when you select a Removable Disk in Windows Explorer.

Disconnecting the USB cable

After completing the file transmission, you must disconnect the cable in the following way:

1 Double-click on the green arrow in the taskbar on the bottom right of the window. Disconnect the USB cable.



2 Select the USB device, and then press the **[Stop]** button.



Note :

The green arrow is not displayed on the Task Bar in Windows 98 system. If “READY” message is shown in Display window, please disconnect the USB cable.

Continued...

Formatting

1 Select the removable disk icon and click the right mouse button to select **[Format]**.



2 Press the **[Start]** button.

- All saved files will be formatted.
- You can change the name of removable disk by selecting **[Volume label]**.

Notice :

- If you format yepp in the PC without installing the provided program, it may not read the data.
- Care must be taken as formatted files can not be recovered.
- By formatting, all previously preset menus will be initialized.

Note :

- You can format by executing "YP-55 Format" located under **[Start]** → **[All Programs]**

Installing CD Ripper

Insert the Installation CD in the CD-ROM drive.

Click **[Next]** button in the series of windows that appear.



Refer to the Help file **[?]** after executing CD Ripper.

Note : When you install the CD-Ripper, Windows displays "for Windows 98", but you can use it with Windows 2000 and XP as well.

Listening to Music with yepp

First, insert the battery and connect the earphones to the player.

Playing Music
(Power On)

When you press the ▶/■ button, the yepp logo appears and a music/voice file is played.



Stopping Music
(Power Off)

When you press the ▶/■ button while playing, the music stops. If no buttons are pressed within 10 seconds (changes depending on settings), the yepp automatically powers off.

- You can also turn off the power by pressing and holding the ▶/■ button on the main body.

Note :
- WMA files can only be played at bit rates between 48Kbps and 192Kbps.
  [supplied by Windows Media Player (Ver 8.0)] WMA files less than 48Kbps may not be played.
- Power off time can be set in the MENU mode.

Setting up Volume/Hold Functions

Adjusting the Volume

Move the

button on the side of the yepp player to adjust the volume while playing.

Note :
- Volume ranges from 00 to 30.
- Press to adjust the volume by one level.
  Press and hold to increase or decrease the volume in greater increments.

HOLD Function

Under Hold mode, buttons will not work.

Slide the switch on the player in the direction of the arrow.

※ When a button is pressed, " HOLD!" message will appear on the display.



Changing Modes

1 Press the MODE button briefly while the player is stopped.

2 Move to the mode you want by using the MODE button, and then press the MODE button.



Note :
- You will exit from the Mode Switching function if no action is taken for 15 seconds or if another button is pressed during mode switching.
- The Voice Mode settings will not be saved if the mode is switched to the Music or FM modes or if the power is turned OFF.

Recording Voice

To Record Voice

1 Slide the REC/ENC switch to the ENC position to begin Voice Recording.

2 To stop the recording, move the REC/ENC switch in the opposite direction and a new voice file will be created.



Note :
- Recording is done in the order of V001,V002.....
- If the Memory is full, the Voice Recording is stopped automatically.
- The Voice Recording is also enabled in Music Mode.
- The backlight will not illuminate during a Voice Recording.
- The number of saved voice files and hours available for recording will be displayed when Voice Mode is selected while the player is stopped.
- To Record Voice, be sure nothing is connected to the ENC jack.
- Voice Recording does not work in FM Mode or when the Line cable is connected.

MP3 Encoding

1 Connect the Audio Output port on the external audio source (or the Line Out port) to the ENC port on the device with the Line cable.



2 Slide the REC/ENC switch to the ENC position begin MP3 encoding.

3 Slide the REC/ENC switch to the REC position while recording to stop the encoding, and a new encoding file will be created.

- Recording will take place in the order of L001, L002, L003…. When the recording is finished, the files will be saved as MP3 files.

Note :

- Bit Rates can be set within the range of 32Kbps~128Kbps.
- To pause during Encoding, press the ▶/■ button.
  Press the button once again to recommence recording.
- Volume can be adjusted from level 0 to 10 while monitoring the Encoding.

Notice :

- Do not disconnect the Line cable during Encoding.
- If the battery is not charged enough, encoding will not be done.
- Adjust the volume of the external audio source to a suitable level and encode it.
  If the volume level is extremely high, the sound quality may not be good.

Searching for Music/Voice Files

Note :

- VBR(Variable Bit Rate) file: MP3 file whose compression rate changes when played.
- With VBR files, Turning the lever to the ⏬ direction within 5 seconds from the start of the track may not result in the previous track playing.
- With VBR files, the actual running time may differ from that of the player display.
- This player may not play back MPEG1 LAYER1 files.

Searching for Specific Parts in PLAY Mode

- To find a certain track, turn the ⏬/⏫ lever to the up or down during play.
- Release the lever and the lever will return to its original position. Playing will recommence in the normal way.



Searching for Music Files in PLAY Mode.

- The next track will play if you turn the lever to the ⏫ direction during play.
- To move to and play the previous track, turn the lever to the ⏬ direction within 5 seconds of the beginning of play. To move to and play the current track from the beginning, turn the lever to the ⏬ direction 5 seconds after the beginning of play.



Searching for Music Files in STOP Mode.

Turn the lever to the up or down while the player is stopped. It moves to the ⏬/⏫ track and plays it.



Listening to FM Radio

While the player is stopped, select FM Mode by using the MODE button.

Manual Search for a Frequency

Turn the ⏮/⏭ lever briefly to find the frequency you want.



Automatic Search for a Frequency

Turn and hold the ⏮/⏭ lever to automatically find and tune in to a transmitted frequency.



Manual Storage of a Frequency

Upon finding a frequency you want, press the ▶/■ button to store the frequency.



Note :

- To exit from FM Mode, press the button.
- Mono (MO) or Stereo (ST) is automatically selected.

Automatic Storage of a Frequency

- Press and hold the WOW button while in FM Mode.
- Frequencies within the range of 88MHz to 108MHz are automatically selected and stored.
- Frequencies are automatically stored, starting from 1.



Number of Channels to be Stored

Searching Stored Frequencies

- Press the **WOW** button briefly while in FM Mode.
- The stored frequencies are successively searched.



MUTE Function

- Press and hold the MODE button while in FM Mode.
- As soon as 'MUTE' appears on the display no sound will be heard.
- To cancel the MUTE function, adjust the volume with MODE Switch.



Note :

- You can store up to 20 frequencies.
- You can replace an existing frequency with a new one but you cannot delete a stored frequency.

FM Encoding

FM Encoding to MP3

1 Slide the switch to the ENC position during FM

- Encoding of the currently transmitted FM broadcast begins.

2 Slide the switch to REC.

- A file is created and the encoding stops.
- Files are saved in order of F001, F002, F003… and stop automatically when the memory is full.

Loop Repeating

Loop Function

Starting Point

While playing music files, press the button briefly at the beginning of the loop you want to set.

A appears in the display.



Ending Point

Press the button briefly again to set the end of the loop.

A↔B appears in the display.
The loop is played repeatedly.

Note :

- Press the button briefly to cancel the loop.
- Loop Repeat is automatically released if you Speed Search with ⏬/⏫ button.

Setting up SRS (Sound Retrieval System)

1 Press the **WOW** button while in Music Mode.

2 Press the **WOW** button to move, and then press and hold the **SRS** button to select the mode you want.



- **SRS** : You will hear 3D Stereo sound.
- **TRUBASS**: This is a bass boost feature that adds fullness to the sound.
- **WOW** : This feature allows you to enjoy the SRS and Trubass features simultaneously.
- **EQ** : Plays at the last EQ setting you made.

Note :

- SRS(●) WOW is a trademark of SRS Labs, Inc.
  WOW technology is incorporated under license from SRS labs, Inc..
- Please adjust the volume to a suitable level, as the volume may increase in the SRS setting.
- This unit supports sampling frequencies of 32KHz, 44.1KHz or 48KHz.
- You can set SRS functions only in Music Mode.

Setting up MENU

To switch to Menu Mode, press and hold the MODE button while in Music/Voice Mode.

Press the MODE button briefly to select the menu you want.

To exit from Menu Mode, press and hold the MODE button once again.



- **PLAY MODE** : To select track repeating mode.
- **EQUALIZER** : To use equalizer function.
- **FILE** : To delete or format music files.
- **DIRECT PLAY** : It plays files encoded in Music, FM or Line.
- **SETTING** : To change the basic setup options of the display.
- **EXIT** : To exit **MENU.**

Note :

- In MENU mode, no input for 15 seconds will cancel the MENU mode.
- Menu mode will be released if any button other than the MODE button is pressed.

Repeating Tracks

Track Repeating Function

1 In **MENU**, select **PLAY MODE**. (refer to “Setting up MENU”)

2 In **PLAY MODE**, use the MODE button to move to the mode you want and press the MODE button to select.



- **INTRO**: To play the first 10 seconds of each track.
- **NORMAL**: To play all the tracks in order one time.
- **REPEAT ONE**: To repeat one track.
- **REPEAT ALL**: To repeat all tracks.
- **SHUFFLE**: To play tracks at random.
- **EXIT**: To move to the upper menu.

Setting up EQ

EQ Function

1 In **MENU**, select **EQUALIZER**. (refer to “Setting up MENU”)

2 In **EQ**, use the MODE button to move to the setting you want (out of the 4 settings) and press the MODE button to select.

- Select the DBB Mode if you want to fine-tune the sound.

3 If you want to manually adjust the equalizer, select **User** and **Bass/Treble**.

- The adjustment range of Bass/Treble is 0 to 10.



Note :

- DBB is for Dynamic Bass Booster, which enhances bass response.

Managing Files

Deleting

1 In **MENU**, select **FILE.** (refer to “Setting up MENU”)

2 In **FILE**, select **DELETE** and the mode the target file is in.

3 Move to the file you want to delete and then press the

button.
Select **CONFIRM** and then select **CANCEL** to exit from the setup.



Formatting

1 In **MENU**, select **FILE.** (refer to “Setting up MENU”)

2 In **File**, select **FORMAT.**



Note :

- All files will be deleted when formatting the built-in memory.
- It is recommended that formatting be carried out on a PC that has the provided program installed as formatting in the Menu may take a long time.

Setting up DIRECT PLAY

DIRECT PLAY Function

● Set the player to this function for playing MP3 and FM encoded songs.

1 In **MENU**, select **DIRECT PLAY**. (refer to “Setting up MENU”)

2 In **DIRECT PLAY**, move to the mode you want by pressing the MODE button, and then press the MODE button to select.

DIRECT PLAY
MUSIC FM ENC LINE ENC EXIT
DIRECT PLAY
MUSIC FM ENC LINE ENC EXIT
DIRECT PLAY
MUSIC FM ENC LINE ENC EXIT
DIRECT PLAY
MUSIC FM ENC LINE ENC EXIT

● **MUSIC**: To play music files that are downloaded in the music folder
● **FM ENC**: To play encoded files in the FM ENC folder
● **LINE ENC**: To play encoded files in the LINE ENC folder
● **EXIT**: To move to the previous menu

Customizing Options (Display)

Setting Function

1 In **MENU**, select **SETTING**. (refer to “Setting up MENU”)

2 In **SETTING,** use the MODE button to move to the function you want to change and select the function by using the MODE button.


SETTING
DISPLAY BACK LIGHT BEEP CONTRAST SCROLL SPEED
SETTING
DISPLAY BACK LIGHT BEEP CONTRAST SCROLL SPEED
SETTING
DISPLAY BACK LIGHT BEEP CONTRAST SCROLL SPEED
SETTING
DISPLAY BACK LIGHT BEEP CONTRAST SCROLL SPEED
SETTING
DISPLAY BACK LIGHT BEEP CONTRAST SCROLL SPEED
SETTING
POWER OFF TIME DEFAULT VOL WOW LEVEL ENCODE EXIT
SETTING
POWER OFF TIME DEFAULT VOL WOW LEVEL ENCODE EXIT
SETTING
POWER OFF TIME DEFAULT VOL WOW LEVEL ENCODE EXIT
SETTING
POWER OFF TIME DEFAULT VOL WOW LEVEL ENCODE EXIT

Continued...

DISPLAY

- **PLAY TIME**: displays current play time
- **REMAIN TIME**: displays remaining play time
- **USED SIZE**: displays using memory
- **FREE SIZE**: displays remaining memory



BACK LIGHT

- Use the MODE / VOL button to set the Backlight "ON" time.
- The setting range of Backlight-On Time is 0 to 10 seconds.

✻ The backlight does not illuminate when the residual battery level is insufficient.



BEEP

- Use the MODE / VOL button to set the BEEP mode.
- **BEEP ON**: A beep sounds each time a button is pressed.
- **BEEP OFF**: No beep sounds when a button is pressed.

Note :

- No beep sounds while playing or recording of a music/voice file even when set to 'BEEP ON'.



CONTRAST

- Use the MODE / VOL button to set the Contrast.
- The setting range of the contrast, which adjusts the brightness of the screen, is 0 to 10.



Continued...

SCROLL SPEED

- Use the MODE button to set the Scroll Speed.
- The setting range of the scroll speed, which adjusts the speed of the track title flow, is 0 to 10.



POWER OFF TIME

- Use the MODE button to set the Power Off Time.
- The setting is 5 different levels ranging from 0 to 25 seconds. The power will turn off after the set time if no button is pressed when the playback ends.



Note :

- When '0 second' is set, the power will not turn off but will remain in Standby Mode.

DEFAULT VOLUME

- Use the MODE button to set the Default Volume.
- The default volume setting range of the unit is 0 to 25. If the Volume is above 25(26-30) when you turn the device off, it will default to 25 when the device is turned back on.
- If the Volume is set to 25 or lower when you turn the device off, it will return to that setting when it is turned back on.



WOW LEVEL

- The levels of SRS and TRUBASS can be adjusted.
- Select the mode you want by using the MODE button.
- The level for SRS and TRUBASS can each be set within the range of 0 to 10.



Continued...

ENCODE

AUTO SYNC

- Use the button to set the Encode AUTO SYNC.
- **ON**: Automatically creates a file for each track.
- **OFF**: All songs recorded in ENC mode are saved in a single file.



Note :

- What is Auto Sync?
  Auto Sync senses the input sound during MP3 encoding.
  If there is no sound, encoding stops automatically. Otherwise, encoding keeps going. You can save MP3 files separately.
  Example) If you encode a CD including 10 music files with MP3, 10 MP3 files are created automatically when set the Auto Sync to ON.
- Auto Sync function can support from 64Kbps to 128Kbps.

BIT RATE

- Use the button to set the Encode BIT RATE.
- When encoding music into an MP3 file, you can select one of the following bit rates: 32Kbps, 48Kbps, 64Kbps, 96Kbps and 128Kbps.



Firmware Upgrade

1 Download the latest Firmware from www.samsungyepp.com

2 Install the latest Firmware program on your PC.

3 Connect to the USB port on your PC using the USB cable or adapter while holding the play button on the main body. If you press the Play button more than 5 seconds, the “Player Recovery Device” message is displayed on Device Manager as shown in the picture on the right.

4 Run the upgrade program.

5 When the program is running, the screen will show the progress.

6 The upgrade window will appear when the Recovery process is complete. Ensure that ‘Quick Download’ is deselected. Click Start to begin the upgrade.

7 The upgrade is complete.

8 Reconnect the USB for the driver to be newly recognized.

Note :

- If you do not release Quick Download, you cannot proceed to upgrade.
- When the Quick Download is deselected, formatting will commence at the same time, and the saved file will be deleted.
- If your operating system is Windows 98, you will have to restart the YP-55 Upgrade program.

Description of Buttons (yepp player)

BUTTON	STATUS	PRESSING LENGTH	RESPONSE
▶/■	Power Off		Power On, and play
	Play		Pause(When no button is pressed for 10 seconds, yepp powers off automatically) Press and hold the 2 seconds Power Off.
	MENU Mode		Cancel
	Intro Play		Cancels Intro, returns to Play mode
▲▲	Play	Less than 1 second	Play the next track
	Play	Longer than 1 Second	Fast forward search in PLAY mode
	Stop/Pause		Play the next track
	FM Mode		Frequency Search
	MENU Mode		Cancel MENU
▼▼	Play	Short	Within 5 seconds from the start: Play the previous track After 5 seconds from the start: Play the beginning of the current track.
▼▼	Play	Longer than 1 Second	Fast reverse search in PLAY mode
	Stop/Pause		Play the previous track
	FM Mode		Frequency Search
Volume	Play or Stop Mode		Volume increase/decrease
	MENU Mode		Move MENU
Mode	Play	Short	Set the starting point for loop function
	During Loop Setting	Short	Loop mode
	Loop Mode	Short	Cancel loop mode
	Stop	Short	Changing modes (music ↔ voice↔ FM)
	Play or Stop Mode	Longer than 2 Seconds	Enter MENU
	MENU Mode		Selection/Exiting MENU
	Play or Stop Mode		Voice recording
	VoiceRecording/Encoding		Voice Recording/Encoding Stop
	Line in Connect		MP3 Encoding
	FM Mode		FM Encoding

MENU Table


MENU
● Select with the MODE VOL button and move.
PLAY MODE
INTRO
NORMAL
REPEAT ONE
REPEAT ALL
SHUFFLE
EXIT
EQUALIZER
NORMAL
CLASS
JAZZ
ROCK
DBB
USER
BASS
TREBLE
EXIT
EXIT
FILE
DELETE
MUSIC
VOICE
FM ENC
LINE ENC
EXIT
FORMAT
CONFIRM
CANCEL
EXIT
DIRECT PLAY
MUSIC
FM ENC
LINE ENC
EXIT
SETTING
DISPLAY
PLAY TIME
REMAIN TIME
USED SIZE
FREE SIZE
EXIT
BACK LIGHT
BEEP
CONTRAST
SCROLL SPEED
POWER OFF TIME
DEFAULT VOL
SRS
TRU BASS
EXIT
WOW LEVEL
ENCODE
AUTO SYNC
BIT RATE
EXIT
EXIT
EXIT

Troubleshooting

yepp does not work and the LCD displays nothing.
- Check the battery capacity
- Check to see if the battery is inserted to the right poles (+ , −)

In PLAY mode, music is not played after pressing the ►/■ button
- Check to see if MP3 or WMA files are saved in the built-in memory.
- Check to see if the HOLD switch is locked.
- Check if the REC button is on.
- Check if the memory is full.

Files cannot be downloaded.
- Check to see if the driver is installed correctly in the computer.
- Check the connection between yepp and computer.
- Check and/or replace the battery, turn on the yepp's power.
- The Windows98 operating system limits the number of files you can save. Please save your music files by creating a subfolder.

Backlight does not work.
- Check the backlight setup.
- When the battery power is low, the backlight will go out.

The buttons do not work.
- Check setting of Hold switch.
- When the message "Please Reformat" is displayed, please format your YP-55 by installing the software using Windows Explorer.

---

yepp keeps being turned off.
- In Stop mode, the power is automatically turned off after ten seconds (changes depending on settings).
- Check to see if there are files saved in it.

Something's wrong with play time displayed during Play mode.
- "VBR SONG" message is displayed while VBR (Variable Bit Rate) file is playing.

LCD window is dark
- Check Contrast

Specifications

Model	YP-55
Built-in Memory capacity	256MB(YP-55 V)/192MB(YP-55 i)/128MB(YP-55 H)
Voltage	1.5V X1 (AAA/LR03 size alkaline battery)
Playing time	lasts up to 15hours (Alkaline battery, MP3 128Kbps, Vol level 20)
Dimensions/Weight	1.02 X 3.19 X 1.02 inches/1.6oz (without battery)
Case	Plastic/Aluminum
Noise Ratio	80dB with 20kHz LPF (1KHz 0dB)
Earphones Jack Output Power	5mW(Max 10mW)/CH (16 Ω)
Output Frequency Range	20Hz~20kHz
Operating Temperature Range	-5 ~ +35°C (23 ~ 95F)
FM Frequency	88.0 ~ 108.0 MHz
FM Signal to Noise Ratio	45 dB
FM T.H.D	1%
FM Useable Sensitiivity	10 dB
File Support	MPEG1/2/2.5 Layer3 (8Kbps ~ 320Kbps, 8KHz ~ 48 KHz) WMA (48Kbps ~ 192Kbps, 8KHz ~ 48KHz)

SAMSUNG ELECTRONICS

Samsung Limited Warranty

Samsung Electronics Canada Inc. (SECA),
warrants that this product is free from defective material and workmanship.

SECA further warrants that if this product fails to operate properly within the specified warranty period and the failure is due to improper workmanship or defective material SECA will repair or replace the product at its option.

All warranty repairs must be performed by a SECA authorized service centre. (The name and address of the location nearest you can be obtained by calling toll free 1-800-726-7864 or visiting our web site at www.samsung.ca)

Labour	Parts
one (1) year (carry-in)	one (1) year

On carry-in models, transportation to and from the service centre is the customer's responsibility.

The original dated sales receipt must be retained by the customer and is the only acceptable proof of purchase. It must be presented to the authorized service centre at the time service is requested.

Exclusions

This warranty does not cover damage due to accident, fire flood and/or other acts of God; misuse, incorrect line voltage, improper installation, improper or unauthorized repairs, commercial use, or damage that occurs in shipping. Exterior and interior finish, lamps and glass are not covered under this warranty. Customer adjustments which are explained in the instruction manual are not covered under the terms of this warranty. This warranty will automatically be voided for any unit found with a missing or altered serial number.
This warranty is valid only on products purchased and used in Canada.

MEMO

MEMO